

## Specifikationer

<b>Battery:</b>	2-cell - Lithium-ion battery
<b>Battery capacity:</b>	5000mAh
<b>Output:</b>	Standard USB with 5V - 1A
<b>Input:</b>	Micro USB with 5V 1A
<b>Dimensions:</b>	24x44x105mm
<b>Weight:</b>	132g
<b>Material:</b>	Aluminum and plastic
<b>Full charge time:</b>	4 hours
	Rechargeable over 500 times
<b>Operating temperature:</b>	-20°C~50°C
<b>Storage temperature:</b>	-20°C~50°C
<b>Temperature level:</b>	approx. 42°C~49°C
<b>Short circuit protection:</b>	YES
<b>Overcharge protection:</b>	YES
<b>Overload protection:</b>	YES
	CE, Rohs and GS Approved
<b>Protect the environment:</b>	Dispose at recycle station or in approved battery box



Nordic Heat ApS · Kratbjerg 240 · DK-3480 Fredensborg  
+45 2717 0000 · Service@NordicHeat.dk · Nordic-Heat.com



# NORDIC HEAT®

STAY WARM AND FOCUSED



incl. 220V EU (2A) USB charger + 3i1 USB cable

## HANDWARMER

with built-in Powerbank

#6507 - 18650-5000mAh - Black or camouflage color

The premium choice of Your  
Game Changing Technology



## Instructions

Please read this manual before use.

## Guidance for Handwarmer function

### Turn on the heat:

Hold button for 4-5 seconds - The indicator flashes slowly red and starts in low (42°C)

### Switch from low to high temperature (49°C):

Press the button once - the indicator flashes quickly red.

### Approx. duration per charge:

Low temperature (about 42°C): Approx. 4 hours

High temperature (about 49°C): Approx. 3 hours

## Handwarmer Charging

- Use the supplied 220V EU 2A USB plug and USB 3in1 cable together.
- Connect the cable with the handwarmer micro USB to the USB port on the plug.
- During charging or supplying a device, hand warmer function is not possible.
- When you start using your new Hand warmer/Powerbank for the first time, it is very important to charge and discharge the device 100% the first 8-10 times - this provides the best and longest durability.

## Power for insoles / charging

When the power bank is connected to your Nordic Heat soles or another digital product, it automatically generates power or starts charging the connected unit - phone or similar.

The red and blue LED lights will light constantly. (connect within 5 sec.)

Tap the button twice to turn off.

Tap the button once to turn on again.

## Power status

When the device is off, press the button once - three blue indicators indicate the power status.

## Please note

- Do not expose to high temperatures, fire, water or liquid.
- Should be kept dry and cool
- Do not expose the USB port and plug for short circuit as this may damage the product.
- **Charge the handwarmer before summer storage.**

